



- USE: Indoor
- MATERIAL: Teakwood, Rattan
- FINISH: White - Natural
- STYLE: Classic, Farmhouse, Hamptons
- GENERAL WARNINGS: Do not place near direct sources of heat. Keep away from direct solar light. Do not use abrasive products like acetones, bleaches, solvents, etc. Sharp elements can scratch the product surface.
- GENERAL CARE: Clean brushing it with a soft brush or with a dry cloth. If some liquid is spilt over the product, clean it as fast as possible to avoid making stains. Dust it with a duster.
- VARIATION TYPE: Natural color tone, light, and environment conditions may distort the color perception of the product.
- ORIGIN COUNTRY: Indonesia (ID)